



REMOTE INTERFACE SPECIFICATIONS

ACC 060-MCD

Remote Reset Switch Assembly – Momentary switch used to reset refrigerant monitor via external reset connections.

Electrical:

Requires no power. Connect Reset and GND terminals on ACC 060-MCD to reset and GND terminals on IR-SNIF-MCD (Terminal board 3, terminals 4 and 5).

Physical:

7" h x 7" w x 4.5" d (nominal).

